

## WIRING INSTRUCTIONS

# SMM Steel Hardtop V2, V4 ISUZU D-MAX RT50 2012+




FUNCTION	HARDTOP WIRING	VEHICLE WIRING
Constant Power(Dome Light)	Red	White
Rear Demister	Yellow/Red	Black/ Brown
Central Locking(Lock)	Blue	Blue (Plug A)
Central Locking(Unlock)	Green	Blue (Plug A)
Earth	Black	Body of the car
Brake Light	Red	Red (Plug B)
Earth	Black	Black (Plug B)




- Plug A is located at the front of the vehicle on the driver side behind the kick panel.
- Plug B is behind the rear tail light.
- The rest of the connections are above the accelerator pedal and under the rear window.

Plug A.




Blue to Blue (Central Locking- Lock)

► Green to Blue (Central Locking- Unlock)




Red to White (Constant Power-Dome light)

Black to Body of the car (Earth)



Yellow/Red to Black/Brown (Rear Demister)

### Plug B



Red to Red (Brake Light)

Black to Black from hardtop loom (Earth)

### Running the loom

You will find an opening with a grommet sealing it under the passenger rear seat to run the loom out under the vehicle. Then run the loom to the rear of the vehicle behind the tail light.



Version 1.0 Last update: 16/01/2017

#### **PLEASE NOTE**

- Avoid drilling holes in the vehicle. There are always openings into the cabin underneath the vehicle or at the rear.
- Using a L.E.D test light, test all electrical components of the vehicle before and after wiring the hardtop to ensure that everything works correctly.
- Ensure you replace all vehicle trim and return the vehicle interior back to how it was found.

Version 1.0 Last update: 16/01/2017